



STEP 1 – PRIOR TO INSTALLATION

- A) Bushwacker only approves installing the flares according to these written instructions with the hardware provided. WARNING: Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. DO NOT USE: Loctite, SuperGlue, or similar products on the hardware or the flares.**
- B) Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER. Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D) Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E) Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F) Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint BEFORE installing flares. Spray inner fender wells with undercoating AFTER flare attachments have been completed.
- G) Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.
- H) Care & Cleaning:** Bushwacker fender flares are built to last; any detergent you use to wash your vehicle is sufficient to clean the flare. Do not use any harsh abrasive detergents.

Nissan Pocket Style® Fender Flares Set of 4

Set Part #70909-02
Rev-1 4/18/2016

TOOLS FOR EASY INSTALLATION:

- Utility Knife
- Vinyl or Plastic Putty Knife
- Automotive Trim Pry Tool
- #2 Right Angle Ratcheting Screwdriver
- Socket Wrench
- 1/2" Socket
- Drill with 1/4" Bit

PLEASE READ: Dirt and debris can become lodged between the fender flares and the vehicle's fenders, causing scratching and paint wear from vibration. Lund International is not responsible for any damage, and the installation of our fender flares is done with the buyer's understanding that this scratching and paint wear may occur.

LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.

Included in Hardware Kit:


- | | | | | | | |
|---|--|---|---|---|--|--|
| 1. 
CL1-0022,
#10 "U" Clip,
2 pcs | 2. 
SW1-0056,
#8 x 3/4"
PH Screw,
2 pcs | 3. 
SW1-0049,
10 x 3/4" Phillips
Tapping Screw,
14 pcs | 4. 
RV1-P001,
1/4" Black Nylon
Retainer,
2 pcs | 5. 
CL1-0009,
Long "U" Clip,
Magni 565
6 pcs | 6. 
MT1-0034,
1" x 1.5" x .06"
Blk 3M Foam Tab,
6 pcs | 7. 
SW1-0058,
#10 x 5/8" Phillips
SS Truss Screw,
6 pcs |
| 8. 
SW1-0067,
5/16 x 18 x 3/8"
SS Torx Screw,
33 pcs | 9. 
NU1-0019,
5/16-18 Jam Fin.
Nylock Nut,
33 pcs | 10. 
WA1-0012,
.320 x .700 x .03
SS Washer,
33 pcs | 11. 
SW1-0052,
T-45 Torx Bit,
1 pc | 12. 
GP1-0025,
EX4008 Wiper
Style Edge Trim,
318 inches | 13. 
ET1-0002,
Edge Trim Tool,
1 pc | |

COMPONENT LIST



STEP 2 - EDGE TRIM INSTALLATION

- A) Peel two to three inches of red vinyl backing away from Edge Trim (GP1-0025) tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).
- B) Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.



Pocket Hardware Installation:



Put a Washer (WA1-0012) on each Bolt (SW1-0067).



Put each Bolt/Washer combination through a pocket hole in the flare, Bolt head and Washer on the outside.



Place a Nut (NU1-0019) over the end of each Bolt and tighten, using a 1/2" wrench for the Nut and the supplied Torx Bit (SW1-0052) for the Bolt. Repeat for remaining pockets.

Front Flare Installation Procedures (Driver's Side):



Using a #2 Phillips Screwdriver, remove factory mud flaps if installed,



Using a #2 Phillips Screwdriver, remove factory flares if installed.



Install supplied clip (CL1-0022) on end of inner bracket.



Using a #2 Phillips Screwdriver, remove factory screw from wheel well.



Use factory screw to install inner bracket in wheel well where shown.



Position flare on fender. Line up holes in flare with the factory holes and start the two 3 supplied screws (SW1-0049) where indicated in picture. *Do not fully tighten screws.*



Install a supplied screw (SW1-0056) into the hole in the flare and into the bracket. Tighten all screws.



Push in on the front of the flare. Using a drill with a 1/4" bit, use the hole in the flare as a guide and drill a hole into the wheel well.



Install a supplied push retainer (RV1-P001) into the hole drilled in the previous step.




Installation complete.

Rear Flare Installation Procedures:



If Factory Mudflaps are installed, use a #2 Phillips Screwdriver to remove them.



If Factory Flares are installed, use a #2 Phillips Screwdriver to remove them. If no Factory Flare is installed, go to Step 17.



16
After removing the Factory flare, remove 3 factory installed clips.



17
Install a foam tab (MT1-0034) over 3 top center metal tabs in the wheel well



18
Install supplied long clips (CL1-0009) over the foam tabs.



19
Position flare on rear fender and install 3 supplied screws (SW1-0058) through flare and into the clip holes.




20
Install 4 supplied screws (SW1-0049) through holes in flare and into the existing factory holes.



21
Installation complete.

Edge Trim Tool Procedures:



Using supplied Edge Trim Tool (ET1-0002), seat edge trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



Using flat end of supplied Edge Trim Tool (ET1-0002), seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.